



Software

DEMCO AUTOMATION www.demcowedge.com

BASELINE


BASE CHASSIS CONFIGURATION SOFTWARE

BASELINE BENEFITS

- Allows easy custom configuration of **DEMCO WEDGE** base chassis to meet your internal requirements and specifications.

STANDARD FEATURES

- **LIGHT TOWER SET-UP** Almost every plant has different standards on how they want the light tower to operate. Some want green to be running, some want blinking green, etc. With the **BASELINE** software, this operation can be easily changed by clicking check boxes.
- **CHASSIS OPTIONS** There are a variety of options available for the base chassis. Some of these include air switches, part past pick-off sensors, dial direction, etc. With the **BASELINE** software, these options can be enabled in the software by following instructions on the respective fields.



DESCRIPTION

BASELINE is a configuration utility that is used to set-up the family of **DEMCO WEDGE** base chassis.

Typically, this software is used to initially configure the base chassis for a specific assembly task. All options such as light towers functionality, dial direction, part past pick off sensors, and many others are configurable with this software.

TRAINING CLASSES AVAILABLE

PLEASE CONTACT DEMCO FOR INFORMATION AND SCHEDULES



HOW TO ORDER

BASELINE IS SUPPLIED FREE OF CHARGE WITH ANY DEMCO CHASSIS PURCHASE. IT IS NOT AVAILABLE FOR INDIVIDUAL SALE

CALL TOLL FREE 1-888-41-WEDGE